

IMPORTANT NOTICE – READ CAREFULLY
Stop & Waste Ball Valves Installation Instructions

INSTRUCTIONS AND PRECAUTIONS

1. During installation note the flow direction indicated on the valve. The drain hole is located on the outlet side of the valve. **Incorrect flow direction will cause the valve to leak constantly in the closed position.**
2. If valve is to be buried, backfill with "pea" gravel around valve to keep drain hole unobstructed.
3. Handle valve carefully before and during installation. Protect threads... keep clean...Do not drop or throw valve. **Do not use a pipe wrench.**
4. Always use an approved sealant or teflon tape on tapered pipe threads.
5. Use only smooth-jawed, adjustable wrenches that fully and evenly engage the product wrench flats, not on round surfaces. Loose fitting wrenches and pipe wrenches will distort the valve and cause leaks.
6. **Always pressure test the service line and ball valve before backfilling.** Inspect all valves, fittings, joints, and pipe. Test valves for proper operation.
7. Backfill and compact earth with care to avoid damage or stress to service line, valve, or curb box.
8. Protect from freezing, which may distort ball. Do not forcibly try to open or close valve if froze. This will destroy the valve.
9. To ensure proper valve performance the valve must be in **Full Open** or **Full Closed** position.
10. 1-1/2" & 2" Stop and Waste Ball Valves are designed to withstand pressures up to 150 PSI, 3/4" & 1" 300 PSI.

WARNING: Do not use on gas lines. Installation on gas lines can result in serious injury or death.



The Ford Meter Box Company, Inc.
 P.O. Box 443, Wabash, Indiana, USA 46992-0443
 Telephone: 260/563-3171 FAX: 800-826-3487
 Overseas FAX: 260/563-0167
<http://www.fordmeterbox.com>

9/15

#200062



The Ford Meter Box Company, Inc.
 P.O. Box 443, Wabash, Indiana, USA 46992-0443
 Telephone: 260/563-3171 FAX: 800-826-3487
 Overseas FAX: 260/563-0167
<http://www.fordmeterbox.com>

All merchandise is warranted to be free from defects in material and factory workmanship. We provide free of charge new products in equal quantities for any that prove defective within one year from the date of shipment from our factory. Manufacturer shall not be liable for any loss, damage, or injury, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for his intended use and user assumes all risk and liability whatever in connection therewith. No claims for labor or consequential damage will be allowed. The foregoing may not be changed except by agreement signed by an officer of the manufacturer.

No other warranties are applicable or may be implied, including the implied warranty of merchantability and the implied warranty of fitness for particular purpose and any warranty relating to infringement or the like, all of which are disclaimed.

WARRANTY

IMPORTANT NOTICE – READ CAREFULLY
Stop & Waste Ball Valves Installation Instructions

INSTRUCTIONS AND PRECAUTIONS

1. During installation note the flow direction indicated on the valve. The drain hole is located on the outlet side of the valve. **Incorrect flow direction will cause the valve to leak constantly in the closed position.**
2. If valve is to be buried, backfill with "pea" gravel around valve to keep drain hole unobstructed.
3. Handle valve carefully before and during installation. Protect threads... keep clean...Do not drop or throw valve. **Do not use a pipe wrench.**
4. Always use an approved sealant or teflon tape on tapered pipe threads.
5. Use only smooth-jawed, adjustable wrenches that fully and evenly engage the product wrench flats, not on round surfaces. Loose fitting wrenches and pipe wrenches will distort the valve and cause leaks.
6. **Always pressure test the service line and ball valve before backfilling.** Inspect all valves, fittings, joints, and pipe. Test valves for proper operation.
7. Backfill and compact earth with care to avoid damage or stress to service line, valve, or curb box.
8. Protect from freezing, which may distort ball. Do not forcibly try to open or close valve if froze. This will destroy the valve.
9. To ensure proper valve performance the valve must be in **Full Open** or **Full Closed** position.
10. 1-1/2" & 2" Stop and Waste Ball Valves are designed to withstand pressures up to 150 PSI, 3/4" & 1" 300 PSI.

WARNING: Do not use on gas lines. Installation on gas lines can result in serious injury or death.



The Ford Meter Box Company, Inc.
 P.O. Box 443, Wabash, Indiana, USA 46992-0443
 Telephone: 260/563-3171 FAX: 800-826-3487
 Overseas FAX: 260/563-0167
<http://www.fordmeterbox.com>

9/15

#200062



The Ford Meter Box Company, Inc.
 P.O. Box 443, Wabash, Indiana, USA 46992-0443
 Telephone: 260/563-3171 FAX: 800-826-3487
 Overseas FAX: 260/563-0167
<http://www.fordmeterbox.com>

All merchandise is warranted to be free from defects in material and factory workmanship. We provide free of charge new products in equal quantities for any that prove defective within one year from the date of shipment from our factory. Manufacturer shall not be liable for any loss, damage, or injury, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for his intended use and user assumes all risk and liability whatever in connection therewith. No claims for labor or consequential damage will be allowed. The foregoing may not be changed except by agreement signed by an officer of the manufacturer.

No other warranties are applicable or may be implied, including the implied warranty of merchantability and the implied warranty of fitness for particular purpose and any warranty relating to infringement or the like, all of which are disclaimed.

WARRANTY